

4237 Latex Additive

DS-1079-0315



1. PRODUCT NAME

4237 Latex Additive

2. MANUFACTURER

LATICRETE Pty Ltd. 29 Telford Street Virginia, QLD 4014 Australia

Telephone: 07 3865 1599
Toll Free: 1800 331 012
Fax: 07 3865 2250
Internet: www.laticrete.com.au

3. PRODUCT DESCRIPTION

4237 Latex Additive is a specially designed latex additive for use with 211 Crete Filler Powder to make a high strength latex thin bed and medium bed adhesive up to 15 mm. For installing all types of tile, stone and agglomerates.

Also for use with Portland cement to make slurry bond coats for mortar beds and for use with thin set adhesives to give improved performance and longer open time.

To achieve longer open time under tropical or desert conditions, the use of LATICRETE Thin-Set Adhesive (290 Super Floor & Wall Thin-Set Adhesive) is recommended instead of 211 Crete Filler Powder.

Uses

Used for installation of all types of ceramic tile, brick, natural stone and agglomerates. 4237 Latex Additive offers the speed and economy of adhesives with the permanent, water resistant dependability of Portland cement. Can also be mixed with PERMACOLOR® Grout to make coloured adhesive for the installation of paper face mounted glass mosaic tiles.

Advantages

- Superior bond strength.
- Flexible and shock resistant; rated for extra heavy traffic conditions.
- Weather and frost resistant for interior and exterior use in all types of climates.
- Proven performance; used in all types of applications for over 50 years.

 Safe, economical and easy to use; non-hazardous, non-flammable.

Suitable Substrates

- Concrete
- Cement terrazzo
- Brick masonry
- Cement plaster
- Concrete masonry
- Cement backer board*
- Cement mortar beds
- Ceramic tile and stone
- Gypsum wallboard (interior only)
- Consult cement backer board manufacturer for specific installation recommendations and to verify acceptability for exterior use

Packaging

19 litre pail; 32 pails per pallet 5 liter jerrycan; 3 jerrycans per carton

Approximate Coverage

Per 19 litre pail of 4237 Latex Additive when mixed with 75 kg of 211 Crete Filler Powder

 $25 - 30 \text{ m}^2$ using a 6 mm x 6 mm square notched trowel $18 - 23 \text{ m}^2$ using a 6 mm x 9 mm square notched trowel

Shelf Life

Factory sealed containers of this product are guaranteed to be of first quality for five (5) years if stored indoors and off the ground at temperatures $>0^{\circ}$ C and $<43^{\circ}$ C.

Limitations

- Use LATAPOXY® 300 Adhesive for installing green marble or water sensitive natural stone and agglomerates.
- Use a white thin set adhesive when installing white or light coloured natural stone.
- Adhesives/mastics, mortars and grouts for ceramic tile, pavers, brick and stone are not replacements for waterproof membranes. When a waterproofing membrane is required, use a LATICRETE Waterproofing Membrane.
- Note: Surfaces must be structurally sound, stable and rigid enough to support ceramic/stone tile, thin brick and similar finishes. Substrate deflection under all live, dead and impact loads, including concentrated loads, must not exceed L/360 for thin bed ceramic tile/brick installations or L/480 for thin bed stone installations where L=span length.

Cautions

- During cold weather, protect finished work from traffic until fully cured.
- Wait 14 days after the final grouting before filing water features with water at 21°C.
- Keep out of reach of children.

4. TECHNICAL DATA

When mixed with 211 Crete Filler Powder, meets and exceeds the requirements of AS ISO13007-2013 as a C2S1 adhesive.

VOC

Green Building Council of Australia Green Star Office Design V_3 IEQ-13

37 grams/litre as VOC content per coating

Working Properties

4237 Latex Additive mixed with 211 Crete Filler Powder at 21°C

Open Time	20 minutes
Pot Life	5 hours
Time to Heavy Traffic	24 hours
Average Wet Density	1700 kg/m³

Specifications subject to change without notification. Results shown are typical but reflect test procedures used. Actual field performance will depend on installation methods and site conditions.

5. INSTALLATION

Unless otherwise noted in this document all work shall be in accordance to AS3958.1 & 2

Surface Preparation

All surfaces should be between 4°C and 32°C and structurally sound, clean and free of all dirt, oil, grease, loose peeling paint, concrete sealers or curing compounds. Rough or uneven concrete surfaces should be made smooth with LATICRETE Latex Portland Cement underlayment to provide a wood float (or better) finish. Dry, dusty concrete slabs or masonry should be dampened and excess water swept off. Installation may be made on a damp surface.

Note: Latex Portland Cement Mortars do not require a minimum cure time for concrete slabs. All slabs must be plumb and true to within 5 mm in 3 m for thin-set installations. Expansion joints shall be provided through the tile work from all construction or expansion joints in the substrate. Follow the Australian Standards requirements for Expansion Joints in AS3958.1 Section 5.4.5 and AS3958.2 Section 4.5 or TCNA detail EJ-171 "Movement Joints — Vertical & Horizontal". Do not cover expansion joints with adhesive.

Mixing

Stir 4237 Latex Additive thoroughly before use.

Use approximately 5 litres of 4237 Latex Additive to 20 kg of 211 Crete Filler Powder. Place 4237 Latex Additive in a clean plastic pail. Do not dilute. Add 211 Crete Filler Powder to 4237 Latex Additive and mix to a smooth, trowelable consistency. Allow adhesive to slake for 5 – 10 minutes. Adjust consistency if necessary. Remix and apply with the proper sized notched trowel.

Note: For the installation of paper-face mounted glass mosaic tile, mix approximately 2.5 litres of 4237 Latex Additive with 10 kg of PERMACOLOR® Grout.

Application

Apply adhesive to the substrate with the flat side of the trowel, pressing firmly to work into surface. Comb on additional adhesive with the notched side.

Note: Use the proper sized notched trowel to insure full bedding of the tile. It is essential that enough adhesive is used to completely cover the back of the tile with a minimum 2 mm to 3 mm uniform thickness. Spread as much adhesive as can be covered with tile in 15-20 minutes. Back butter large tiles

>200 mm x 200 mm to provide full bedding and firm support. Place tiles into wet, sticky adhesive and beat in using a beating block and rubber mallet to imbed tile and adjust level. Check adhesive for complete coverage by periodically removing a tile and inspecting bedding adhesive transfer onto back of tile.

Grouting

Grout installation after a minimum of 24 hours curing time at 21°C. Grout with PERMACOLOR Grout; or, Sanded Grout or Smooth Grout mixed with 1776 Grout Enhancer. For maximum stain resistance use SPECTRALOCK® PRO Grout.

Slurry Bond Coats

Mix in the ratio of 19 litres of 4237 Latex Additive with 1.5 - 2 x 20 kg bags of 211 Crete Filler Powder with a high speed mixer to make a smooth creamy slurry bond coat for use on suitable surfaces under mortar beds. Do not allow slurry bond coat to skin or dry prior to the application of the mortar bed. See TDS1009 for further information.

Cold Weather Note

The setting of Portland cement mortars, adhesive and grouts are retarded by low temperatures. Protect finished work for an extended period when installing in cold weather. For faster setting adhesive use a LATICRETE Thin-Set with 101 Rapid Latex Admix. Do not set tile when surface temperature is below freezing or when substrate is frozen.

Hot Weather Note

Portland The evaporation οf moisture cement and adhesives accelerated mortars is dry conditions. Apply to dampened surfaces and protect freshly spread adhesive and finished work when installing in temperatures over 35°C.

Cleaning

Clean tools and tile work with water while adhesive is fresh.

6. AVAILABILITY AND COST

Availability

LATICRETE and LATAPOXY® materials are available worldwide.

For Distributor information:

Toll Free: 1800 331 012 Telephone: 07 3865 1599

For online Distributor information, visit LATICRETE at www.laticrete.com.au

Cos

Contact a LATICRETE Distributor in your area.

7. MAINTENANCE

LATICRETE and LATAPOXY grouts require routine cleaning with a neutral pH soap and water. All other LATICRETE and LATAPOXY materials require no maintenance but installation performance and durability may depend on properly maintaining products supplied by other manufacturers.

8. TECHNICAL SERVICES

Technical assistance

Information is available by calling

Toll Free: 1800 331 012 Telephone: 07 3865 1599 Fax: 07 3865 2250

Technical and safety literature

To acquire technical and safety literature, please visit our website at www.laticrete.com.au

9. DISCLAIMER

- The information contained in this document is given in good faith and to the best of our knowledge is true and accurate
- This information is subject to change without notice and it is the responsibility of the user to obtain up to date and current information.
- The use of this product is beyond our control and liability is assumed by the user when used incorrectly and not in accordance with LATICRETE guidelines.
- The manufacturer is not responsible for any loss or damage arising from incorrect usage of this product.
- The specifier or other party responsible for the project must ensure that the details in this data sheet are appropriate for the intended application and that additional detailing is performed for specific design or any areas that fall outside the scope of this specification.
- Efflorescence is a normal condition of Portland cement and is not covered by any warranty. The use of LATAPOXY® 310 Stone Adhesive, LATAPOXY 300 Adhesive, SPECTRALOCK® PRO Grout and SPECTRALOCK 2000 IG will not contribute to any noticeable efflorescence.

LATICRETE Pty Ltd

29 Telford Street Virginia, QLD 4014 Australia 1800 331 012

www.laticrete.com.au

© 2015 LATICRETE Pty Ltd All trademarks shown are the intellectual properties of their respective owners.